EVO GRILL COOK TOP



STEP 1

Be sure that all regulator valves are in the OFF position.

STEP 2

Remove hood and cook top.

STEP 3

Remove labeled lower bar and secure propane tank in bottom fitting.

STEP 4

Connect hose to propane tank. Tighten counter-clockwise and open valve.

STEP 5

Locate **IGNITION** button beneath the regulator valve panel.

STEP 6

Turn regulator valves to LITE position.

STEP 7

Press **IGNITION** button until the pilot bars ignite.

STEP 8

Replace cook top.

STEP 9

Turn regulator valves to desired setting.



consistently deliveringtm

EVENT SOURCE EventSource.com

877.901.0000

PANACHE EVENTS

PanacheEvents.com

800.30.PARTY (72789)

AFTER HOURS

Call above toll free numbers and press Option 2. Please leave a message and we will respond shortly.

SKU 3020-800 INCLUDES

Hood Cook Top 1 Drip Pan



VIDEO LINK

Video coming soon.



NOTE

This unit can ONLY use a 20lb propane tank.

PROPANE USE



Tank = 20lb



20lb @ 2-3hrs