ELECTRIC STEAM TABLE



STEP 1

Fill each well to FILL line inside of the well (approx. 4 QT) DO NOT OVERFILL.

STEP 2

Plug the power cord into **GROUNDED** 120V outlet.

STEP 3

Turn the power switch to **ON** position.

STEP 4

Cover wells with **LIDS FOR FULL FOOD PANS** and set temperature knob on each well to highest setting to preheat. Let stand for approximately 20-30 min.

STEP 5

Place food pans of hot food into wells.

STEP 6

Set heat control to desired setting.



consistently deliveringtm

EVENT SOURCE EventSource.com 877.901.0000

677.901.0000

PANACHE EVENTS
PanacheEvents.com
800.30.PARTY (72789)

AFTER HOURS

Call above toll free numbers and press Option 2. Please leave a message and we will respond shortly.

SKU 304-600 INCLUDES

3 Wells

3 - 2" Deep Full Food Pans/Lids 10' Extension Cord



WARNING

DO NOT overfill the wells to avoid water overflowing when food is placed in pans.