

6 BURNER PROPANE STOVE/OVEN



INSTRUCTIONS

STEP 1

Be sure that all knobs on the stove are in the **OFF** position.

STEP 2

Connect hose to the propane tank. Tighten counter-clockwise and open valve.

STEP 3

Open oven door and remove the bottom panel to light the pilot.

STEP 4

Push red button near the bottom front and hold while lighting the pilot (inside the oven).

STEP 5

Once the pilot is lit, continue to hold in the red button for approximately 30-40 seconds.

STEP 6

Release the button, if the pilot did not light, repeat steps 4 and 5.

STEP 7

With the pilot lit, replace the bottom panel and close the oven door.

STEP 8

To light the stove turn the desired knobs to the **ON** position.

STEP 9

Proceed to light the venter of each burner.

STEP 10

Stove will then be ready to use. Adjust flames to desired heat for cooking.



EVENT SOURCE
PANACHE EVENTS

consistently delivering™

EVENT SOURCE
EventSource.com
877.901.0000

PANACHE EVENTS
PanacheEvents.com
800.30.PARTY (72789)

AFTER HOURS

Call above toll free numbers and press Option 2. Please leave a message and we will respond shortly.

SKU 302-200 INCLUDES
2 Shelves



VIDEO LINK

See how to use this rental item:
<http://vimeo.com/228723009>



NOTE

It is recommended that you use a long grill lighter to avoid contact with hands.

Always use in a well-ventilated area.

OUTDOORS IS PREFERRED!

PROPANE USE



Tank = 40lb



Stove = 4.5hrs