

COFFEE MAKER



INSTRUCTIONS

STEP 1

Fill coffee pot with COLD water to the desired amount.

STEP 2

Add coffee to basket (see equivalent below).

STEP 3

Plug coffee pot into standard electrical outlet.

STEP 4

When coffee has finished brewing, remove basket. The pot will keep the coffee hot.

CLEANING

Rinse out the inside of the coffee pot and basket before returning. Never immerse coffee pot in water!

BREWING TIME

Approximately 1/2 hour to brew coffee in 30-60 cup urns
Approximately 1 hour in 90-100 cup urns

COFFEE EQUIVALENTS

Number of Cups	Coffee Measure
36	3 - 1/3 cups
55	3 - 2/3 cups
100	6 - 2/3 cups



EVENT SOURCE
PANACHE EVENTS

consistently delivering™

EVENT SOURCE
EventSource.com
877.901.0000

PANACHE EVENTS
PanacheEvents.com
800.30.PARTY (72789)

AFTER HOURS

Call above toll free numbers and press Option 2. Please leave a message and we will respond shortly.

SKU 345-300 INCLUDES

55 Cup Coffee Maker
Lid
Stem
Basket F / Coffee

SKU 345-400 INCLUDES

100 Cup Coffee Maker
Lid
Stem
Basket F / Coffee



WARNING

DO NOT immerse the base of the fountain in water!

DO NOT plug in unit before adding water to prevent damage.



NOTE

1 lb of coffee is equal to approximately 4 and 3/4 cups of ground coffee.