

# ELECTROSTATIC SPRAYER 16L



## INSTRUCTIONS

### STEP 1

Ensure electrical cord is connected from spray gun to backpack.

### STEP 2

Unscrew cap and fill tank with approved disinfectant solution being careful not to spill any on outside of tank or spray gun.

### STEP 3

Place the unit on your back.

### STEP 4

Turn on the machine by moving the power switch to the **"ON"** position located on the backpack. To efficiently disinfect your surface, start by spraying from top to bottom.

### STEP 5

Let your surface dry. Dry time varies from one to five minutes depending on material and amount distributed.

### STEP 6

When finished, turn the power switch to **"OFF"**. Be sure to flush out tank and line with clean water.



EVENT SOURCE  
PANACHE EVENTS

consistently delivering™

**EVENT SOURCE**  
EventSource.com  
877.901.0000

**PANACHE EVENTS**  
PanacheEvents.com  
800.30.PARTY (72789)

#### AFTER HOURS

Call above toll free numbers and press Option 2. Please leave a message and we will respond shortly.

**SKU 310-4200**



#### WARNING

This product requires protective equipment, and cannot be used on food safe items.

#### DISINFECTANT USE



Tank = 16 Liters



#### NOTE

Spray radius = 15 Feet.