

FISH COOKER/PROPANE BURNER

Includes: Open Valve

Options: 20lb or 40lb Propane Tank, Grill Hood



INSTRUCTIONS

STEP 1

Connect the propane tank and open the valve.

STEP 2

Slightly open the valve on the Fish Cooker/Propane Burner.

STEP 3

Light the burner using **EXTREME** caution.

STEP 4

Adjust air intake for the blue flame.

AFTER HOURS:

Contact your local branch.



NOTE

Use a long grill lighter to avoid contact with hands.

Always use a well-ventilated area.

Outdoors is preferred.

PROPANE USE

A 20lb propane tank will last for approximately 6 hours. A 40lb propane tank will last for approximately 11 hours.