

# NACHO CHEESE DISPENSER



## INSTRUCTIONS

---

### STEP 1

Plug the machine into a 120V electrical outlet.

### STEP 2

Preheat the dispenser for about one hour.

### STEP 3

Preheat the nacho cheese bag to about 140°.

### STEP 4

Open the door by pulling the door from left to right. Place the cheese bag on the tray with the spout and the tube directed downward.

### STEP 5

Open the tube by turning the cam counterclockwise.

### STEP 6

Guide the tube through the pump slot from top to bottom.

### STEP 7

Close the clamp by rotating the cam clockwise.

### STEP 8

Close the door and cut the remaining tube 1/4 inch below the door with clean, sanitized scissors. The tip of the tube should be visible and extend outside of the dispenser.

### STEP 9

Depress the button to begin operation.

---

#### To dispense cheese:

- Hold food under dispensing tube.
- Press dispensing button until desired amount of cheese has been dispensed.

#### Removing cheese bag:

- Open the door by pulling forward from the left side.
- Open the tube clamp by rotating the cam counterclockwise.
- Remove the tube from the pump slot by grabbing the tube from the lower end and raising it upward toward the tray.
- Remove the tubing and the bag by continuing to raise the tube upward until it is clear from the tray.
- Remove the empty bag and the tubing from the oven. Do NOT attempt to carry or lift the empty bag by the end of the tube.



EVENT SOURCE  
PANACHE EVENTS

consistently delivering™

---

**EVENT SOURCE**  
EventSource.com  
877.901.0000

**PANACHE EVENTS**  
PanacheEvents.com  
800.30.PARTY (72789)

#### AFTER HOURS

Call above toll free numbers and press Option 2. Please leave a message and we will respond shortly.

---

#### SKU 562-1700 OPTIONS

Nacho Cheese Bags  
Nacho Cheese Trays  
Nacho Chips, Prepacked

---