

BLACK + WHITE DANCE DECK + PARQUET DANCE FLOOR



EVENT SOURCE
PANACHE EVENTS

consistently delivering™



INSTRUCTIONS



MALE



FEMALE

STEP 1

Begin the installation by laying down your first panel in any one corner and pointing the male Dance Deck in the two directions that additional panels are to be added.

STEP 2

Place the next panel so that the female Dance Deck line up over the top of the male loops on the first panel. It's important to make sure that all female and male Dance Deck pieces are facing the same direction as the first panel throughout the entire installation.

STEP 3

Gently step along the joint of the two panels. You will hear and feel the Dance Deck snap into place as you go.

STEP 4

Once the two panels are joined, repeat steps 1 through 3 remembering to keep the Dance Deck aligned until your floor is complete.



EDGING

After your dance floor is completely set, start to lay the edging. The male edging will lay under the female dance floor pieces. The female edging will lay on top of the male edging pieces. Gently step along the joint of the edge panels. You will hear and feel them snap into place as you go.

EVENT SOURCE
EventSource.com
877.901.0000

PANACHE EVENTS
PanacheEvents.com
800.30.PARTY (72789)

AFTER HOURS

Call above toll free numbers and press Option 2. Please leave a message and we will respond shortly.

BLACK DANCE DECK
SKU 460-2001/2194 INCLUDES
Full Panels
Edging

WHITE DANCE DECK
SKU 456-2000/2083 INCLUDES
Full Panels
Edging

PARQUET
SKU 457-2000/2107 INCLUDES
Full Panels
Edging



NOTE

Avoid excessive exposure to moisture.